



1612 N Broad Street
Lansdale, Pa 19446
(215) 362 - 7368

44 W Ridge Pike
Limerick, Pa 19468
(610) 489 - 2334

HOT DOG CART INSTRUCTIONS

1. Read through these instructions carefully.
2. In center of cart, place approximately 1 to 2 gallons of Hot Water and Hot Dogs.
3. Open bottom drawer, insert and light Sterno. Thereafter, close and lock drawer.
4. The time it takes for the dogs to heat is dependent on the quality and quantity of the hotdogs being cooked. Please adjust as needed. Normal heat time is approximately 45 minutes.

Cleaning instructions:

1. Blow out and remove Sterno.
2. Do not clean the hotdog cart while cart is still hot.
3. Empty water from center.
4. Use soap and water to clean.

Suggestions:

1. Hot dogs must be completely unfrozen.
2. Frozen hot dogs must be immersed in water for at least 2 hours for fully unfrozen.
3. Do not keep the hot dogs cooking for too long in order to keep their taste.