

# Game Changer

## Field Goal Kick & Soccer Darts



1612 N Broad Street  
Lansdale, Pa 19446  
(215) 362 - 7368

44 W Ridge Pike  
Limerick, Pa 19468  
(610) 489 - 2334

### Set up instructions for Games.

- Untie the strap around the game.
- Unroll the game. Pay attention to how the game is rolled. (you will have to roll it back up again when finished).
- Unfold the game. (at least until you find the fill tube). Fill tube is located on one of the back legs of the game.
- Attach the blower fan to the fill tube using the Velcro straps. Secure tightly.
- Turn on the blower fan and inflation will happen in a few minutes. (help it up if needed)
- Stake down the four corners of the game with stakes provided. There are top tether points to tie rope to if needed. Do not operate outside in wind in excess of 20 mph. If it is breezy, it is recommended to stake the direct wind corner before inflation.
- Your game is ready to play.
- Have fun! But of course use common sense.
- When finished please pack up the game in the manner it was received. Please make sure the game is clean and dry. Remember to include the blower fan, stakes and all balls or accessories.

